

SPT[®]

Mini Electronic Pulse Massager



UC-029
Operating Manual

Contents

Introduction.....	2
Safety warnings.....	3
Part identification	4
Operating instructions.....	5
Program schematics.....	6-8
Recommended use points.....	8
Trouble shooting.....	9
Warranty info.....	10

Introduction

UC-029 Mini Electronic Pulse Massager is a pain relief product, which delivers electric impulses to tired and sore muscles. These impulses are generated by the device and delivered through the connecting wires and electrodes to the target body areas. The impulses mimic the action potential coming from the central nervous system to trigger contraction of the muscle. UC-029 is portable, compact, and stylish in design. It may help relieve pain in various parts of the body, such as the lower back, shoulders, joints, hands and feet. Using UC-029 properly will provide you with a healthy and comfortable life.

Features of UC-029 Mini Electronic Pulse Massager:

1. Liquid crystal display (LCD) with battery usage indicator
2. Build-in rechargeable lithium battery, DC 3.7V
3. Frequency: 0-200 Hz
4. Main unit measure: 1.69 x 0.51 x 3.30 inches
5. Net weight of the main unit: 1.2 oz (.075 lb)
6. Six massaging modes
7. Adjustable intensity and up to 60 minutes countdown timer
8. Accessories included: 4 electrode pads, 2 lead wires, 1 USB adapter, 1 USB cable, and 2 wire/pad holders

Safety warnings

If you have one of the following conditions, please consult with your physician before purchasing or using this device.

Acute disease; malignant tumor; infective disease; pregnant; heart disease; high fever; abnormal blood pressure; lack of skin sensation or an abnormal skin condition; any condition requiring the active supervision of a physician.


- Do not use this unit if you are using an implanted electronic medical device such as a pacemaker or other life-maintaining device.
- Do not use this unit if you are wearing electronic medical devices for monitoring health functions.
- Do not use this device while driving.
- Do not use this device while sleeping.
- Do not use this device in high humidity areas such as bathroom.
- Keep this device out of reach of children.
- Stop using this device at once if you feel pain, discomfort, dizziness or nausea, and consult your physician.
- Do not attempt to move the electrode pads while the device is operating. Turn off the device before moving or removing the electrode pads.
- Do not use the device around the heart, on the head, mouth, pudendum or blemished skin areas.
- Keep the device away from wet, high-temperature and/or direct-sunlight place.
- Medical Electrical Equipment needs special precautions regarding electromagnetic compatibility (EMC) and needs to be installed and put into service according to the EMC information provided.
- Portable and mobile radio frequency (RF) communication equipment can affect Medical Electrical Equipment.

Operating temperature range: 32°F to 118°F

Operating humidity: 10% to 85%

Atmospheric pressure: 400hPa to 1060hPa

Part Identification



- | | |
|-------------------------|----------------------|
| 1. Channel outlets | 7. Timer adjustment |
| 2. USB port | 8. Play/Pause button |
| 3. LCD screen | 9. USB charger |
| 4. On/off switch | 10. USB cable |
| 5. Intensity adjustment | 11. Electrode pads |
| 6. Mode selector | 12. Lead wires |

Operating Instructions

Before initial use, charge the massager for a minimum of 8 hours.

1. Make sure the power switch is in the OFF position.
2. Connect lead wire(s) by inserting the plug into the Left and/or Right channel outlets.
3. Connect electrode pads to lead wires by snapping them on. This should be done before applying pads to the skin.
4. Place pads to treatment areas (such as shoulder or lower back), make sure pads do not touch each other. Press down firmly and ensure a full and firm contact with skin.
5. Switch the power switch to ON position.
6. Press the M (mode) button to select desired massage mode.
7. Press the “+” button to increase massage intensity. Pressing the “-“ button would decrease massage intensity.
8. During a massage session, pressing the center "► II" button would pause the operation. Press again to resume.
9. Press the T (timer) button to set massage time, up to 60 minutes, in 10-minute increments.


Note:

- Timer continues to count down even when session is paused.
- To conserve battery, unit will power off 5 seconds after a session completes. To begin another session, first switch the power button to OFF position and back to ON.


Recommended practices:

- Duration of 20 minute for each body area.
- Frequency of 1-2 times per day per area.
- Start from the lowest intensity and gradually adjust to a comfortable level on a scale level from 1 to 10.
- Be sure the area to be treated is free of perspiration, dirt and abrasions.
- Good skin care is important for a comfortable use of device. Be sure the treatment site is clean of dirt and body lotion, wipe with an alcohol pad if needed.
- When removing the pads, remove by pulling in the direction of hair growth.
- The electrode pads are disposable and should be replaced when they lose their adhesiveness. However, keeping electrode pads clean will extend their lifespan. Replace pads to the storage holder immediately after use. Avoid touching with fingertips due to grease on fingertips.
- The lifespan of the pads will vary depending on the frequency of use. To purchase additional pads, please contact Sunpentown at 1-800-330-0388 and ask for part number: PAD-029


Program Schematics




Massage Mode




Acupuncture Mode




Tapping Mode




Scraping Mode



Cupping Mode



Kneading Mode



Recommended use points



Troubleshooting

If your device is not operating properly, please check below for common problems and suggested solutions. If the recommended action does not solve the problem, please contact Sunpentown Customer Service at 1-800-330-0388 or service@sunpentown.com.

Stimulation is weak or non-existent

- Be sure skin is clean and pads are firmly attached to skin.
- Be sure the pads are not touching each other.
- Check wire connection and make sure lead wires are securely plugged in.
- Unit's battery is low and needs to be recharged.
- Both pads (of the same wire) must be attached to one person's body in order to feel sensation.

Device does not turn on

- Check if battery is low and needs to be recharged.
- If unit was previously used, switch the power switch to OFF first, then back to ON.

Electrode pads are not sticky

- The pads will lose adhesiveness over use, please contact Sunpentown for replacements.

Skin turns red

- Extended treatment on the same area, stop and wait or treat another area.
- If problem persists, contact your physician.



Your Guarantee

If this product is found to be faulty as a result of faulty materials or workmanship within one year from date of purchase, it will be repaired free of charge.

This guarantee is subject to the following terms:

- Sunpentown must be notified of the fault.
- Proof of purchase must be presented to Sunpentown's nominated representative.
- The warranty will be void if the product is modified, misused or repaired by an unauthorized person.
- The warranty after repair will not be extended beyond the original one-year period.
- All replacement parts will be new or reconditioned.
- Parts, which are replaced, become the property of Sunpentown.
- The warranty applies for the use of the product in the USA only.

What is NOT COVERED:

- Warranty does not include freight charges.
- Incidental or consequential damage caused by possible defects with this product.
- Damage to product caused by improper power supply voltage, accident, fire, floods or acts of nature.
- Failure of product resulting from unauthorized modifications to the product.
- Improper installation or failure to perform the necessary maintenance.

This GUARANTEE is in addition to your Statutory Rights

**SUNPENTOWN INTERNATIONAL INC.
14625 Clark Ave. City of Industry, CA 91745
Tel: 800-330-0388
service@sunpentown.com
www.sunpentown.com**